



purchase in our online store. www.balanzzastore.com

Operation and Instructions – Balanza Digital Luggage Scale

CHARGING YOUR SCALE

Before weighing:

Please connect the micro USB Cable provided with your scale to the connector on the side of the scale and to your usb port on the computer or to you wall connector.
Red light indicates the unit is charging, a green light indicates that the charge is full and complete.
DONOT leave the scale connected to the USB cable for long period of time after it has been fully charged.

You can also use any micro usb cable you already have.

WEIGHING

Before weighing:

Whenever possible, please allow the scale to warm up for 30 seconds after first turning the power on so that the scale will function properly and accurately.

Weighing procedures:

1. Press the button [⏻] to turn On the scale; and hold it for 3 seconds to turn Off the scale.

When power is turned on, all display segments appear on LCD for a few seconds and finally “0” will appear on the display.

2. Select the weighing unit with [weight icon].

Press [weight icon] to select a weighing unit: “kg” or “lb”. Once the unit has been selected, the selected unit will be displayed above the weight value.

3. Start weighing.

a. If you do not use a container for weighing:

Verify the reading is “0”. If not, press [⏻] to display “0”.

Place objects on the weighing strap to weigh.

Lift the object from the ground until hearing the beep sound, this indicates that the weight has been locked and displayed. Set the object down, and read the weight.

b. If you use a bag or other container for weighing:

Place an empty container on the strap and proceed to weigh it. Wait for the stability weighing value to be displayed and press [⏻] to display “0”.

Place the objects to be weighed in the container.

Lift the object from the ground until hearing the beep sound, this indicates that the weight has been locked and displayed. Set the object down, and read the weight.

WARNING

1. The screen can stop functioning properly if mistreated or hit.
2. If the strap shows any signs of wear and/or break please stop using the Balanza Scale.
3. When lifting the object with the Balanza Scale please use the same precautions as any other object, the use of the Scale does not increase your strength or decreases the weight of the object.
4. When securing the strap, please keep your fingers outside the clip.
5. Do not leave the batteries inside the Scale for long periods of time without use.

Error messages:

EEEE: Overload

Instrucciones de Uso

Recargando su Pesa

Antes de Pesar:

Conecte el cable the USB que viene con su pesa en la coneccion lateral de la pesa y a su cargador de pared o Puerto USB de su computador personal.

La luz roja indica que se esta cargando, la luz verde indica que se ha completado el proceso de recarga.

No deje la pesa conectada al Puerto de USB por largo tiempo una vez completada la carga.

Tambien puede utilizar cualquier cable the MICRO USB que ya tenga en casa.

Antes de Pesar:

En lo posible, deje que la balanza se active por 30 segundos después de encenderla por primera vez, para garantizar el funcionamiento correcto.

Mensajes de Error:

EEEE: Demasiado peso

Procedimiento para Pesar:

1. Oprima el botón [⏻] para prender la balanza; oprímalo por 3 segundos para apagarla.

Cuando prenda la balanza, todos los elementos de la pantalla aparecerán por unos segundos y finalmente aparecerá “0”.

2. Seleccione las unidades de peso [icono de peso]

Oprima [Unit] para seleccionar entre kg. o lb. Una vez seleccionada la unidad, esta aparecerá arriba del valor del peso en la pantalla.

3. Comience a Pesar

a. Si no esta utilizando un contenedor.

Verifique que la pantalla muestre “0”, en caso contrario presione [⏻] .

Amarre el objeto a pesar con el cinturón o tira.

Levante el objeto del piso, utilizando la balanza, hasta que escuche el sonido que indica que el peso ha sido registrado en la pantalla. Coloque el objeto en el suelo y lea el peso.

b. Si utiliza un contenedor para pesar el contenido.

Coloque el contenedor o bolso vacío y péselo, una vez que el peso se muestre en la pantalla oprima el

botón de **[0]** para colocar la balanza en cero, la pantalla mostrará "0".

Coloque el contenido dentro del bolso o contenedor.

Levante el Objeto del piso, utilizando la balanza, hasta que escuche el sonido que indica que el peso ha sido registrado en la pantalla. Coloque el objeto en el suelo y lea el peso.

Recuerde: El peso que muestra la pantalla es únicamente del contenido.

PRECAUCIONES

1. La pantalla puede dejar de funcionar correctamente si se golpea o cae.
2. Si el cinturón muestra desgaste o roturas, deje de usar la Balanza.
3. Al retraer el mango no situar la mano entre el aparato y el mismo.
4. Al levantar objetos con la Balanza, use las mismas precauciones que con cualquier otro objeto, el uso de no aumenta su fuerza ni reduce el peso del objeto.
5. Al asegurar el objeto a pesar al cinturón, situar los dedos en los extremos superior e inferior del gancho.
6. No dejar las pilas en el aparato por periodos extensos de tiempo sin uso.